

QUICKLOAD TRACTOR SCALE



Save Time, Money, and Fuel on every Load

On-board scales are the key to increased efficiency in the transportation industry. Eliminate out-of-route miles, lost hours-of-service, and wasted fuel driving to use an inground scale. Know how much weight is riding on your Steer and Drive axles from the comfort of your cab. DOT over-weight fines can be a thing of the past, when you use QuickLoad on-board scales.

On-Board Convenience

Keep your customers happy! Avoid the inconvenience of reloading or reworking loads. On-board scales make your job easier because you know immediately if the load is legal, before you get on a public roadway. Get the competitive edge that on-board scales offer. You'll find that on-board scales are well worth the investment!

Air-Weigh®

1730 Willow Creek Circle • Eugene, OR 97402 • www.Air-Weigh.com • (888) 459-3444

QUICKLOAD TRACTOR SCALE



QuickLoad Features

QuickLoad tractor scales measure and display Steer and Drive axle weights. All information is conveniently displayed in either pounds or kilograms. QuickLoad tractor offers a customer determined, optional preset alarms feature that warns operators when goal and target weights are reached.

- Axle group weight measured to within 300 lbs. of a certified scale.
- Dual point calibration ensures accuracy.
- Compensates for temp, altitude, and biometric pressure.
- Weights are digitally displayed in the cab.

Easy to Operate

Simply park your vehicle on level ground with the engine running, and the brakes released. Briefly deflate the air suspension, and inflate to ride height. Steer and Drive weights are displayed on the easy-to-read digital display. Dual point calibration combined with PIN protection ensures accuracy and prevents tampering.

Industry-Leading Support

Air-Weigh is committed to providing superior service. Our dedicated customer support team is ready to answer your installation, and operation questions. Air-Weigh scales are covered by a 3 Year warranty.

For more information, contact an Air-Weigh Fleet Specialist at (888) 459-3444, 7 a.m. – 5 p.m. PST Monday – Friday.

PRODUCT DETAILS

Display
Digital 2" round in-dash

Calibration
Dual-point, PIN-protectable

Accuracy
300 lbs. per axle group

Language
English, Spanish and French

Alarm
Two outputs, with warning and target weight thresholds

Operating temperature
-40° to +85°C; -40° to +185°F

Sensors
Air pressure sensors and deflection sensors in various configurations

Power
9-32V dc

Air-Weigh®

1730 Willow Creek Circle • Eugene, OR 97402 • www.Air-Weigh.com • (888) 459-3444